
Your BT Voyager I065 Wireless Adaptor Guide



Important –

If you are installing this wireless adapter as part of an existing wireless network with a base unit (e.g. BT Voyager 2100), you should install and switch on the base unit before proceeding.

Do not plug in your BT Voyager Wireless Adapter until instructed to do so in this guide. Windows 98 users may require their Windows CD during installation – Please ensure the Windows Installation disc is available before you continue.

Your Wireless Pack Contents:

1 x BT Voyager I065 Wireless Adapter, 1 x Quick Start Guide and CD

Software Installation

Before installing your laptop expansion card, you should install the driver software.

1 Insert the BT Voyager Wireless CD into your computer's CD-ROM drive. The CD will autoplay, bringing up a menu screen from where you can start the installation process.

2 To install, click **Install BT Voyager Wireless Adapter** and click **Next** when the installation wizard starts. You will be asked to read the Software License Agreement, continue by clicking **Yes**.


3 Next you will be asked to confirm where to install the driver files, if you are happy with the default directory, click **Next**.

4 When the driver files have finished copying, click **Finish**. You have now completed the software installation phase.

Hardware Installation

You are now ready to plug in your Voyager I065 adapter into your laptop card slot.

5 Windows will detect the new hardware. Click **Next** on the Windows wizard screen to complete the hardware installation.

6 You can confirm that the driver software has been installed because the BT Voyager Wireless Utility  icon will appear in the system tray, usually in the bottom right of your screen).

7 The Installation is now complete - you can now connect your laptop to your wireless network, following the instructions that came with your wireless router or access point.